HyPET™ 1 Year Preventive Maintenance Kit

Secure your production, save time and get the right parts with Husky Preventive Maintenance kits.

The Husky Preventive Maintenance kit includes all the parts required to perform the annual maintenance of your machine.

The kits are built according Husky maintenance manual recommendations.

They are customized to meet the specific options of your machine.

Replacing consumable elements on regular basis will contribute to

maximizing your machine performance and availability, and securing your production.

With Husky Preventive maintenance kits you will always get the right parts for your machine with the highest quality.

## Annual parts replacement schedule for HyPET™ machine

| Part Descr iption                                       | Position | Repla cement schedule |
|---------------------------------------------------------|----------|-----------------------|
| Coalescing filter and silencer on the oil recovery unit | 1        | 3 months              |
| Oil retrieval filter element                            | 1        | 6 months              |
| Clamp lock cylinder auto-lube cartridge (if equipped)   | 2        | 3 months              |
| Hydraulic oil filter element                            | 3        | 6 months              |
| Vacuum pump air inlet cartridges                        | 4        | 6 months              |
| Vacuum pump carbon dust separator filter cartridge      | 4        | 6 months              |
| Vacuum silencer                                         | 5        | 6 months              |
| Air regulator filter element                            | 6        | 12 months             |
| Hydraulic Tank Breather cap                             | 7        | 12 months             |
| Transfer Breather Filter                                | 8        | 12 months             |
| Blow Down Filter                                        | 9        | 12 months             |
| Pressure filter element (if equipped)                   | 10       | 12 months             |

## **Maintenance Instructions:**

For detailed maintenance instructions refer to the documentation provided with your machine.

For additional copies of machine documentation contact Husky Spare Parts Centers.

## www.husky.co www.huskyparts.com

Americas - English: +1 (800) 465 4875 Americas - Portuguese: +55 (11) 4589 7200 Americas - Spanish: +52 (55) 5089 1160


Europe: +352 52115 4300

Russia: +7 495 232 94 50

Europe: 008000800 4300 | India: +(91) 44 2747 6426

China: +800 820 1667 / Outside of China: +800 4875 9477

Japan & ANZ: +(81) 42 788 1190



**HUSKY** 

Advantage+