

HyperSync™ / HyCAP4™ 1 Year Preventive Maintenance Kit

Secure your production, save time and get the right parts with Husky Preventive Maintenance kits.

The Husky Preventive Maintenance kit includes all the parts required to perform the annual maintenance of your machine.

The kits are built according Husky maintenance manual recommendations.
They are customized to meet the specific options of your machine.
Replacing consumable elements on regular basis will contribute to **maximizing your machine performance and availability**, and **securing your production**.

With Husky Preventive maintenance kits you will always get **the right parts** for your machine with **the highest quality**.


Annual parts replacement schedule for HyperSync™/ HyCAP4™ machine

Part Description	Position	Replacement schedule
Coalescing Filter and Silencer on the Oil Recovery Unit	1	every 3 months
Hydraulic Clamp Lock Cylinder Auto-Lube Cartridges (if Equipped)	2	every 6 months
Pressure Filter Element	3	every 6 months
Electric Mold Stroke Fan Filter	4	every 6 months
Air Regulator Filter Elements	5	every 12 months
Hydraulic Tank Breather Cap	6	every 12 months
Oil Retrieval Filter Element	7	every 12 months

Maintenance Instructions:

For detailed maintenance instructions refer to the documentation provided with your machine.

For additional copies of machine documentation contact Husky Spare Parts Centers.



Machine shown with guards removed for illustration purposes only.
Never run the machine without guarding in place.
Machine image is a graphical representation only.
Actual machine may vary based on machine options.

www.husky.co www.huskyparts.com

Americas - English: +1 (800) 465 4875
Americas - Portuguese: +55 (11) 4589 7200
Americas - Spanish: +52 (55) 5089 1160

Europe: 008000800 4300
Europe: +352 52115 4300
Russia: +7 495 232 94 50

India: +(91) 44 2747 6426
China: +800 820 1667 / Outside of China: +800 4875 9477
Japan & ANZ: +(81) 42 788 1190

